

Identify & Hush Your Smoke Alarms

Smoke alarms have been installed at this property, so you are alerted in the event of a fire.

Smoke Alarm Integrity are the service provider that check and maintain your smoke alarms. They issue Right of Entry paperwork and attend upon our request.

Smoke Alarms are Now Interconnected

As part of a QLD wide upgrade of smoke alarms, your property will have smoke alarms in each bedroom as well as in hallways near to your bedroom and on other enclosed stories.

These alarms will be interconnected, so when one alarm detects smoke, all alarms will sound.

How to Identify & Hush Your Sounding Smoke Alarms

Once you have safely determined that there isn't a fire at the property, please take the following steps:

1. During an active alarm, the red LED on the triggering alarm will flash.
2. Press & release the silence button.
3. Your alarm will silence & enter a reduced sensitivity reset cycle.
4. During the reduced sensitivity reset cycle, the red LED light will flash every few seconds.
5. Your alarm will automatically return to full sensitivity on completion of the reset cycle & the LED light will revert to flashing at normal intervals.

(i) The red LED may appear faint in a well lit room.

(ii) There may be a slight delay in silencing the smoke alarm if it is mid-way through the alarming sequence, due to the timing sequence of the Radio Frequency (RF) interconnection.

Cleaning Alarms

Please use a vacuum to remove dust on and around smoke alarms. This will reduce the likelihood of false sounding.

DO NOT spray cleaners or detergent into or around the smoke alarm.

DO NOT attempt to remove the cover of the smoke alarm to clean inside. This will destroy the alarm and void the warranty.

Please be aware that you may be charged for any removed or damaged smoke alarms.

